



rycobelgroup

Proven quality

RYC-D-05-09-grit feeder

GRIT FEEDER



Expand testing methods for Taber Rotary Abrasers.

The Grit Feeder is used to evaluate three body abrasion caused by the destructive action of fine hard particles. Loose grit passes under a pair of leather clad brass wheels, and serves as the abrasant. The resulting rolling action of the particles contributes to the physical breakdown of materials.

Instrument evenly distributes grit particles.

Positioned over a Taber Rotary Abraser, this freestanding unit deposits aluminum oxide grit particles uniformly and continuously, at a specified rate. After passing under the leather wheels, used grit and any abraded material is removed by the Abraser vacuum system.

Two models offer simple set up.

Mounted off the left side of the Abraser, Model 155 utilizes an alignment guide screw to set the position of the instrument. Grit distributor and vacuum removal nozzle heights are adjusted using a thumbscrew. An alignment block is incorporated into the base of Model 255, to ensure the correct location of the grit feeder in relation to the Abraser. With the ability to mount on either the right or left hand side, two instruments can be used in conjunction with Taber's Dual Rotary Abraser. A telescoping feature allows precise height adjustments, and permits testing of thicker specimens, up to 50 mm (2 inches).

Available in two models

- Model 155 - Hopper capacity, approx. 1,300 grams
- Model 255 - Hopper capacity, approx. 4,500 grams
 - Mounts to left or right side
 - Adjustable height

Standard features

- Plugs into accessory receptacle on rear of Taber Abraser
- Adjustable feed rate
- Alignment guide
- CE Label

Optional accessories (sold separately)

- Standardization Plates (S-38)
- #240 Aluminum Oxide Abradant, 22.5 kg container (S-41)
- U.S. Standard #80 Sieve (S-40)
- Replacement Leather Wheels (S-39)
- Rimmed Specimen Holder (E140-14 or E140-75)
- Quiet Cabinet - Large Top

